



WI-AX1800M

AX1800M Dual-band Wi-Fi 6 Mesh Router
Quick Install Guide


Package content



X1



X1




X1




X1

Overview



Status	Description
Blinking blue slowly	Waiting for setting
Solid green	Wizard setup completed
Blinking red slowly	System restart
	System upgrading
	The signal of Mesh is poor


Set up the Router




Please connect devices according to the above topology.
 Follow the steps for quick Router configuration, using initial setup wizard:

Step 1 Connect your device to router via Ethernet or Wireless


Step 2 Launch your web browser then enter **http://192.168.10.1** in the address bar and specify the default login key: **admin**.



Step 3 Then click **NEXT** button:



Step 4 Choose the device operating protocol **DHCP Client** and click **NEXT** button :




Note:


The following explains three Internet connection types.

PPPoE	ask your Internet service provider (ISP) for user name and password.
DHCP Client	This option requires no user action. Your router as a DHCP client and is automatically assigned the IP configuration from your ISP.
Static IP	ask your ISP for the settings such as IP address, Subnet Mask, Default Gateway, and DNS.


Step 5 Enter specify the SSID and Key of the wireless network and click **NEXT** button :



Step 6 Click **COMPLETE** button to end the quick setup:



Adding Mesh node



1. Press and hold the panel **MESH** button on the Master and the slave for about 3 seconds until it MESH LED blinks.
2. Wait about 1 minute for the MESH LED on the Master and on the slave solid blue. In this case, it means the Master is synced to the slave successfully.

Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within three months after purchase, we will provide you a new product of the same model.
- If the product defects within the three-year warranty period, we will provide the professional maintenance service.
- Proof of purchase and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
- Any other defects that are not caused by workmanship or product quality, such as natural disaster, water damage, extreme thermal or environmental conditions, sticker damaged, warranty card losing will disqualify the product from limited warranty.



Wireless-Tek Technology Limited
 Address: Biaofang Technology Building 402, Bao'an street,
 Baoan District, Shenzhen City, Guangdong, China
 Website: www.wireless-tek.com
 Tel: 86-0755-32811290
 Email: sales@wireless-tek.com
 Technical Support: tech@wireless-tek.com