


Quick Installation Guide

Cloud Easy Smart PoE Switch



WI-PCES306G | WI-PCES310GF | WI-PCES318GF | WI-PCES326GF

1. Package Contents

WI-PCES306G



Switch x 1



Quick Installation Guide x 1




Power Cord x 1



Mats x 4

WI-PCES310GF, WI-PCES318GF, WI-PCES326GF



Switch x 1



Quick Installation Guide x 1



Power Cord x 1




Mounting Accessories
(hook x 2; Mats x 4; screw x 8)

2. Appearance Overview

For WI-PCES306G

• Front panel



Reset button
4*802.3af/at PoE Gigabit ports
2*10/100/1000Mbps RJ45 Ports

• Back panel




Grounding
Power port

• LED indicator

LED	Color	Function
PWR	Green	Off: No Power supply. on: Indicates the Switch has power.
PoE	Orange	Off: No PoE powered device (PD) connected. on: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
Link	Green	Off: The network is not connected. on: A 10/100/1000Mbps network device is connected. Blinking: Data is being transferred

For WI-PCES310GF

• Front panel



LED Indicator
Reset Button
8*802.3af/at PoE Gigabit ports
2*1000Mbps SFP Slots

• Back panel



Grounding
Power port

• LED indicator

LED	Color	Function
PWR	Green	Off: No Power supply. on: Indicates the switch has power.
SFP	Green	Off: No device is connected to the corresponding port. on: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
PoE	Orange	Off: No PoE powered device (PD) connected. on: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
PoE Max	Green	Off: PoE output power is less than 80% of the total power on: PoE output power is greater than or equal to 80% of the total power
Link	Green	Off: The network is not connected. on: A 10/100/1000M network device is connected. Blinking: Data is being transferred.


For WI-PCES318GF

• Front panel



LED Indicator
Reset Button
16*802.3af/at PoE Gigabit ports
2*1000Mbps SFP Slots

• Back panel




Grounding
Power port

• LED indicator

LED	Color	Function
PWR	Green	Off: No Power supply. on: Indicates the switch has power.
SFP	Green	Off: No device is connected to the corresponding port. on: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
PoE	Orange	Off: No PoE powered device (PD) connected. on: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
PoE Max	Green	Off: PoE output power is less than 80% of the total power on: PoE output power is greater than or equal to 80% of the total power
Link	Green	Off: The network is not connected. on: A 10/100/1000M network device is connected. Blinking: Data is being transferred.


For WI-PCES326GF

• Front panel



LED Indicator
Reset Button
24*802.3af/at PoE Gigabit ports
2*1000Mbps SFP Slots

• Back panel




Grounding
Power port

• LED indicator


LED	Color	Function
PWR	Green	Off: No Power supply. on: Indicates the switch has power.
SFP	Green	Off: No device is connected to the corresponding port. on: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
PoE	Orange	Off: No PoE powered device (PD) connected. on: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
PoE Max	Green	Off: PoE output power is less than 80% of the total power on: PoE output power is greater than or equal to 80% of the total power
Link	Green	Off: The network is not connected. on: A 10/100/1000M network device is connected. Blinking: Data is being transferred.

3. Installation


• Desktop installation (WI-PCES306G)



• Wall mounted installation (WI-PCES306G)




• Desktop installation (WI-PCES310GF)




For WI-PCES310GF

• Front panel



LED Indicator
Reset Button
8*802.3af/at PoE Gigabit ports
2*1000Mbps SFP Slots

• Back panel



Grounding
Power port

• LED indicator

LED	Color	Function
PWR	Green	Off: No Power supply. on: Indicates the switch has power.
SFP	Green	Off: No device is connected to the corresponding port. on: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
PoE	Orange	Off: No PoE powered device (PD) connected. on: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
PoE Max	Green	Off: PoE output power is less than 80% of the total power on: PoE output power is greater than or equal to 80% of the total power
Link	Green	Off: The network is not connected. on: A 10/100/1000M network device is connected. Blinking: Data is being transferred.


For WI-PCES318GF

• Front panel



LED Indicator
Reset Button
16*802.3af/at PoE Gigabit ports
2*1000Mbps SFP Slots

• Back panel




Grounding
Power port

• LED indicator

LED	Color	Function
PWR	Green	Off: No Power supply. on: Indicates the switch has power.
SFP	Green	Off: No device is connected to the corresponding port. on: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
PoE	Orange	Off: No PoE powered device (PD) connected. on: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
PoE Max	Green	Off: PoE output power is less than 80% of the total power on: PoE output power is greater than or equal to 80% of the total power
Link	Green	Off: The network is not connected. on: A 10/100/1000M network device is connected. Blinking: Data is being transferred.

For WI-PCES326GF

• Front panel



LED Indicator
Reset Button
24*802.3af/at PoE Gigabit ports
2*1000Mbps SFP Slots

• Back panel



Grounding
Power port

• LED indicator

LED	Color	Function
PWR	Green	Off: No Power supply. on: Indicates the switch has power.
SFP	Green	Off: No device is connected to the corresponding port. on: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
PoE	Orange	Off: No PoE powered device (PD) connected. on: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal PoE supply.
PoE Max	Green	Off: PoE output power is less than 80% of the total power on: PoE output power is greater than or equal to 80% of the total power
Link	Green	Off: The network is not connected. on: A 10/100/1000M network device is connected. Blinking: Data is being transferred.

4. Configuration

• Log in to the switch locally

Let the Switch obtain an IP address and then check the DHCP server to see which IP address was assigned.
The Switch is set to DHCP by default, so it will try to automatically obtain an IP address. If that fails, then it will use the default fallback IP address, 192.168.0.1

To log in, follow these steps:
1. Launch your web browser. Type the appropriate IP address in the address field.
2. The login screen will appear. Enter admin in the Username and Password fields. Login in



• Cloud login switch configuration

1. Log in to the cloud management interface
(No account, you need to register an account to log in. The URL is: <http://cloud2.wireless-tek.com>)



2. Enter the cloud binding switch
(explain: The switch must be connected to the Internet to bind successfully)




Please enter the device serial number to bind a device to the current group, device can be off when binding.

Explanation: The 17-digit SN code of the switch is shown on the sticker on the back of the switch as shown in the figure below.



3. After binding, you can use the Switch in the Tunnel option in the cloud management, and then choose to use EWEB or TELNET to enter the switch. The default account is admin and the password is admin
(Note: The EWEB channel can be created only when the easy smart switch is linked with the other type of Wi-Tek cloud management device, such as cloud L2, L3 management switch, gateway, wireless AP, etc.)



Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Purchase Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

If the product defects within three months after purchase, we will provide you a new product of the same model.
If the product defects within the three-year warranty period, we will provide the professional maintenance service.
Proof of purchase and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
Any other defects that are not caused by workmanship or product quality, such as natural disaster, water damage, extreme thermal or environmental conditions, sticker damaged, warranty card losing will disqualify the product from limited warranty.



Wireless-Tek Technology Limited
Address: BiaoFang Technology Building 402, Bao'an street, Baoan District, Shenzhen City, Guangdong, China
Website: www.wireless-tek.com
Tel: 86-0755-32811290
Email: sales@wireless-tek.com
Technical Support: tech@wireless-tek.com

